


INSTALLATION INSTRUCTIONS

R-model Battery Box




1 Parts identifications and dimensions




2 Preparations

To use the detector, a wireless transmitter and batteries should be prepared. First check the following flowchart.




-Battery Sharing

Power supplied is available from battery box to power the detector and the transmitter.



-Non Battery Sharing




3 Mounting


-Battery Sharing

Do not use batteries of different residual quantities (i.e.: mixing new and used batteries) or of different manufacturers and/or types together. Not observing the above may result in an explosion, leakage of electrolyte, emission of toxic gases or other outcomes that may be harmful to people and property.


1 Remove the battery box cover.



2 Mount batteries and place cover into correct position using indicator on side of battery box.



- 3 Open the transmitter cover and remove the battery.
- 4 Place the dummy battery in the battery case of the wireless transmitter.





⚠ Caution

Do not pull the wire when taking out the dummy battery from the wireless transmitter.

Note>>


- When the dummy battery assemble, do not connect battery leads to power source.
- Make sure that the device is not energized when combining units.
- * Refer to followings how to set the dummy battery unit adoptiong to each battery size.
- 5 Connect the alarm cable to the transmitter and close the cover.






Arrange 3 cells each of CR-123A (recommended) or CR2.


1 Remove the battery box cover.




2 Mount batteries and place cover into correct position using indicator on side of battery box.



3 Connect the alarm cable to the transmitter and close the cover.



4 Connecting



Refer to the installation instructions of each detector for more details. The installation instructions can be downloaded in; www.optex.net



OPTEX CO., LTD. (JAPAN)

URL: www.optex.net

OPTEX INC. / AMERICAS HQ (U.S.)
URL: www.optexamerica.com

OPTEX (EUROPE) LTD. / EMEA HQ (U.K.)
URL: www.optex-europe.com

OPTEX TECHNOLOGIES B.V. (The Netherlands) URL: www.optex.eu OPTEX SECURITY SAS (France)
URL: www.optex-security.com

OPTEX SECURITY Sp.z o.o. (Poland) URL: www.optex.com.pl

OPTEX PINNACLE INDIA, PVT., LTD. (India) URL: www.optex.net/in/en/sec OPTEX KOREA CO.,LTD. (Korea) URL: www.optexkorea.com

OPTEX (DONGGUAN) CO.,LTD. SHANGHAI OFFICE (China) URL: www.optexchina.com

OPTEX (Thailand) CO., LTD. (Thailand) URL: www.optex.net/th/th

Copyright (C) 2018 OPTEX CO.,LTD.